

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- ★ Main rotor blades – Unfolded
- ★ Blade attach pins and quick-release pins – Installed, safetied
- ★ To be checked each flight before takeoff.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.