

2.7.3 Hook/Bumper Assembly

During normal flight operations, hook/bumper assy must be in the fully raised position (limit stop activated).

2.8 PLACARDS AND DECALS

Text:

RETTUNGSWINDE			RESCUE HOIST		
BETRIEBSGRENZEN: AUF	AB		LIMITATIONS:	UP	DOWN
WINDENLAST kp	270	200	WINCH LOAD lbs	600	440
SEILLAENGE	30m		CABLE LENGTH	98ft	

Location: RH windshield frame, in pilot's field-of-view

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 WARNING LIGHT INDICATIONS

WARNING LIGHT INDICATIONS

GEN 1

or

GEN 2

Procedure

EFFECTIVITY 0007-0160

Hoist operation is no longer possible after failure of either generator.

EFFECTIVITY 0161-9999

In addition to the basic FLM procedure for **GEN 1** or **GEN 2** Warning Light Indications, perform the following:

1. Hoist cycle in progress — Complete
2. Non-essential consumers — Off
3. Hoist operation — Continue as required

EFFECTIVITY ALL