


3.2 WARNING LIGHT INDICATIONS

WARNING LIGHT INDICATIONS



Procedure

EFFECTIVITY 0007-0160

Hoist operation is no longer possible after failure of both generators.

EFFECTIVITY 0161-9999

In addition to the basic FLM procedure for **GEN 1** and **GEN 2** Warning Light Indications, perform the following:

- | | |
|--------------------------------|--|
| 1. Hoist cycle in progress | – Complete then discontinue system operation |
| 2. WINCH main switch | – OFF |
| 3. LAND AS SOON AS PRACTICABLE | |

NOTE The cable cutter circuit remains operational regardless of generator status. After a dual generator failure electrical power is supplied to the rescue hoist by the onboard battery resulting in:

- approx 50% increase in time required to raise a max load,
- the cable not being completely reeled in by the winch, and
- approx 10% of the battery capacity is consumed when raising a max load at the max cable length.

EFFECTIVITY ALL

3.3 EMERGENCY CABLE CUTTING

Conditions/Indications

Cutting the hoist cable may be necessary under certain emergency conditions occurring during hoist operation (e.g. single-engine failure at a hover, winch motor failure, cable entanglement, etc).

NOTE The CABLE CUTTER pb of the winch control grip (if installed) is deactivated.

Procedure

CABLE CUTTER switch – Raise guard and activate switch

NOTE Cable cutting may be activated using the pilot's collective lever trigger.