

4. NORMAL PROCEDURES

CAUTION • RESCUE HOIST SHALL BE OPERATED ONLY FROM ONE CONTROL STATION AT A TIME. SIMULTANEOUS CONTROL COMMANDS AT BOTH STATIONS ARE NOT PERMISSIBLE.

- ALLOW BOOM TO REMAIN STATIONARY AT LEAST 5 SECONDS BEFORE REVERSING DIRECTION OF TRAVEL.

4.1 PREFLIGHT CHECK

NOTE Perform hoist checks before first hoist operation of the day. Those checks marked with a star (★) are the minimum required before performing any further hoist missions that same day.

- | | |
|-------------------------|--------------------------|
| ★ Winch/boom assembly | – Condition, integrity |
| ★ Electrical connectors | – Fastened, secured |
| Copilot's seat | – Facing aft as required |

NOTE Operation of the rescue hoist by the hoist operator when seated in the copilot seat is permissible only with the seat installed facing aft and the copilot cyclic and collective controls removed.

WARNING REMOVE COPILOT'S COLLECTIVE LEVER WHENEVER POSSIBLE TO PREVENT UNINTENTIONAL MOVEMENT DURING HOIST OPERATIONS.

- | | |
|--|---|
| Copilot's cyclic stick and collective lever | – Removed as required |
| ★ Retaining harness with extension belt | – Condition, integrity |
| ★ Floor-mounted lug | – Secured, extension belt attached |
| ★ Cable cutting shears | – Attached |
| ★ Winch control grip and cable | – Condition, connected |
| ★ WINCH and CABLE CUTTER TEST indicator lights | – Press to test |
| ★ WINCH main switch | – ON; WINCH indicator light on |
| ★ CABLE CUTTER TEST switch | – Press; indicator light on |
| Control grip thumb switch | – Boom/OUT then WINCH/DOWN; lower hook approx 1 m |
| Hook/bumper assy | – Check as follows: |
| Boot | – Detach at stop plate to expose indicator pins |
| Indicator pins | – Condition, pins must protrude from bottom of stop plate |
| Exposed cable | – Condition |