

- | | |
|---|--|
| Boot

Control grip thumb switch

NOTE Winch will not reel in cable completely when using battery power. Therefore, limit-stop checks should be performed either using an EPU or after starting the engines (generators on).

Pilot's WINCH thumb switch

★ WINCH main switch | – Attach

– WINCH/UP then boom/IN; raise hook until limit stop engages

– Extend boom and lower hook approx 1 m, then raise hook until limit stop engages and retract boom

– OFF; WINCH indicator light off |
|---|--|

4.2 HOIST OPERATION

4.2.1 General

- NOTE**
- On helicopters fitted with Snow Skids (FMS 10-18) or Settling Protectors (FMS 10-20), loads may snag on snow skid/settling protector.
 - To prevent roll out of the load, it is recommended to use a device (ring, D-ring, snap safety hook) with a maximum inner diameter not larger than 40 mm or to apply an adequate operational procedure in compliance with national regulations.

When raising a load, the cable speed is approx 0.5 m/sec (98 fpm).

Connect load to hook using rigid, non-stretchable devices whenever possible.

When picking up several loads, place each hoisted load along RH cabin side opposite the hoist to maintain helicopter lateral balance.

After exposure of hook/bumper assy to salt water, flush as outlined in the Maintenance Manual.

The hoist operator should wear heavy protective gloves.

Ground speed should be zero when picking up or setting down a load.

4.2.2 Procedure

WARNING • WHEN RAISING A LOAD, OSCILLATIONS (ESPECIALLY AT SKID HEIGHT) MUST BE REDUCED BY EITHER:

- USING SHORT INTERRUPTIONS WHEN REELING IN CABLE, OR
- HOIST OPERATOR GRASPING AND MOVING CABLE IN OPPOSITE DIRECTION OF LOAD MOVEMENT WHILE CAREFULLY MONITORING HELICOPTER MOVEMENT.

- FURTHER USE OF RESCUE HOIST IS PROHIBITED WHEN OSCILLATING HOOK EITHER IS REELED IN AT AN ANGLE AGAINST WINCH UNIT OR STRIKES UPWARDS AGAINST WINCH HOUSING.
- STATIC ELECTRICITY BUILD-UP ON CABLE AND HOOK SHALL BE DISCHARGED BY GROUNDING HOOK TO SURFACE.

CAUTION • CHAFING THE CABLE AGAINST THE LANDING GEAR OR EQUIPMENT COULD DAMAGE THE CABLE, WHICH MIGHT:

- SERIOUSLY REDUCE THE CABLE'S ABILITY TO WITHSTAND ITS SPECIFIED LOAD
- CAUSE CABLE -JAM WITHIN THE HOIST
- LEAD TO EXCESSIVE CABLE-WEAR AND CORROSION HENCE REDUCING CABLE-LIFETIME

- IN ORDER TO AVOID CONTACT BETWEEN CABLE AND LANDING GEAR OR EQUIPMENT:
 - THE HOIST BOOM SHALL BE SWIVELLED OUT AS FAR AS PRACTICABLE
 - CABLE OSCILLATIONS SHALL BE KEPT TO A MINIMUM
- WHENEVER THERE IS CONTACT BETWEEN CABLE AND LANDING GEAR OR EQUIPMENT, THE HOIST MOTOR MUST BE STOPPED IMMEDIATELY. BEFORE RESUMING, THE AFFECTED CABLE AREA SHOULD BE INSPECTED TO VERIFY INTEGRITY.

Retaining harness (hoist operator)	– Fastened, adjusted, secured to floor lug
WINCH main switch	– ON
Airspeed	– Reduce to allow door opening
LH sliding door	– Open, secure
Zero ground speed hover	– Establish over hoist operating area
Thumb switch	– OUT, extend boom outboard

CAUTION MAXIMUM CABLE LENGTH IS REACHED WHEN RED COLORED PORTION IS VISIBLE.

- | | |
|---------------------|---|
| Thumb switch | – DOWN, allow hook to touch ground |
| Load | – Secured to hook, ready for lifting |
| Thumb switch | – UP, as necessary to take up any slack in cable |
| Slow vertical climb | – Establish, centering hoist exactly over the load when necessary |

While lifting load:

- | | |
|----------------|-----------------------|
| TORQUE and TOT | – Check within limits |
|----------------|-----------------------|

WARNING REDUCE ANY LOAD OSCILLATIONS.

- | | |
|--------------|---|
| Thumb switch | – UP, raise load to approx skid height, reduce any oscillations |
|--------------|---|

NOTE When load is 50 kg or less, retract boom inboard enough to allow hoist operator to guide cable.

- | | |
|--------------|---|
| Thumb switch | – UP, allow limit stop to activate, guide hook if necessary |
| Thumb switch | – IN, fully retract boom inboard |
| Load | – Secure in cabin and release from hook |

NOTE It may be necessary to reel out a length of cable to bring the load into the cabin. After securing load and releasing hook, fully reel in cable while guiding empty hook.

- | | |
|-------------------|---------|
| LH sliding door | – Close |
| WINCH main switch | – OFF |

5. PERFORMANCE DATA

Helicopter performance remains unchanged with retracted winch/boom (without load).