

3.1.4 Jettisoning Cockpit Doors - Ditching Only

Procedure

CAUTION SHARP OBJECTS WILL PUNCTURE FLOATS; EXIT HELICOPTER WITH EXTREME CARE.

- | | |
|---------------------------------|------------------|
| 1. Door latch | – Release |
| 2. Jettison lever (red colored) | – Push downwards |
| 3. Door | – Push outwards |

NOTE With one hand, hold door at aft end of map case and with the other hand, push door upper forward portion outwards and over the inflated float.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

NOTE The following checks should be performed before each over-water flight.

- | | |
|---------------------------|------------------------|
| Float covers and lashings | – Condition |
| Rubber cords | – Connected to spoiler |

NOTE Rubber cords must be connected to spoiler for over-water flights. For other flights the cords may be stowed on brackets provided on the skids.

- | | |
|-------------------------|-----------------------------------|
| Air supply lines | – Condition, secured |
| Air cylinders | – Condition, secured |
| Cylinder pressure | – Check |
| EMER FLOATS TEST switch | – Press |
| Indicator lights | – Come on |
| FLOATS switch guard | – Closed, break-away safety wired |

5. PERFORMANCE DATA

No change in basic Flight Manual data when the floats are stowed.