

2. LIMITATIONS

2.1 SYSTEM LIMITS

Do not operate the external loudspeakers when the outside air temperature is below -20°C .

Operation of the system must comply with the regulations of the responsible authority.

2.2 SYSTEM INSTALLATION LIMITS

The cross-tube mounted loudspeakers (D134-978) shall not be installed together with the Emergency Flotation System (FMS 10-22).

Removal of the integrated loudspeakers (105S-83801) requires covering the openings in the lower fuselage fairing prior to the next flight.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 SYSTEM OPERATION

Power switch – ON

Volume (slider control) – Adjust

For pilot/copilot operation:

COMM control panel transmit selector switch – PA

Cyclic stick push-to-talk switch – Press

For hand microphone use:

Push-to-talk switch – Press

Power switch – OFF, when operation is completed

5. PERFORMANCE DATA

Climb performance may be slightly reduced with cross-tube mounted loudspeakers due to increased drag.