

2. LIMITATIONS

2.1 AUXILIARY TANK CAPACITY

	ONE TANK		BOTH TANKS	
	Liters	US Gal	Liters	US Gal
Usable Fuel	198.5	52.4	397.0	104.8
Unusable Fuel	1.5	0.4	3.0	0.8
Total	200.0	52.8	400.0	105.6

2.2 SYSTEM INSTALLATION LIMITS

When the Fuel Jettison System (FMS 10-10) is installed, the fuel in the aux tanks is to be considered as non-jettisonable due to the slow rate of transfer (5 liters per minute per tank).

The Cargo Compartment Heating (FMS 10-11) shall not be used when aux tanks are installed.

2.3 PLACARDS AND DECALS

Text:

<u>ACHTUNG!</u>	<u>ATTENTION!</u>
VOR DEM BETANKEN MUSS ZUSATZTANK- AUSLASSVENTIL GESCHLOSSEN SEIN. (COCKPIT-ANZ. "ZU")	BEFORE REFUELING LONG RANGE TANK OUTLET VALVE MUST BE IN CLOSED POSIT. (COCKP.-IND. "CLOSED")
KRAFTSTOFF 200 LTR.	FUEL CAP. 52,8 US. GAL.
MIL-T-5624	JP4 JP5

Location: Adjacent each aux tank filler neck.