
EFFECTIVITY *If Cargo Compartment Heating (FMS 10-11) is installed.*

Text:

**DO NOT OPERATE
1KW-HEATING WITH
LONG-RANGE TANKS
INSTALLED**

Location: Overhead panel adjacent Cargo Heating switch.

EFFECTIVITY ALL

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 CAUTION LIGHT INDICATIONS

CAUTION LIGHT INDICATIONS

**TRANS
FER**

Conditions/Indications

Main tank fuel level is low enough to accept transfer of fuel from one auxiliary tank

- **TRANSFER** caution light on
- Main tank fuel quantity below 200 kp

Procedure

Transfer fuel from aux tank to main tank (see Para 4). If aux tanks are empty pull control panel circuit breakers.

NOTE To avoid an extreme aft CG condition when only one cockpit seat is occupied, transfer aux tank fuel immediately after the **TRANSFER** caution light comes on. Automatic transfer is carried out by selecting the appropriate tank valve before takeoff. When the **TRANSFER** caution light comes on and the aux tanks are empty, the light can only be turned off by pulling the circuit breakers on the control panel.