

3.2 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS

Conditions/Indications

Any helicopter emergency that requires that fuel be transferred before the **TRANSFER** caution light comes on

Selected tank valve fails to open

- L. CLSD (R. CLSD) indicator light remains on, or

Main fuel tank float switch failure

- Main tank fuel quantity is less than 200 kp, however, the **TRANSFER** caution light remains off.

Procedure

- | | |
|--------------------------------------|--|
| 1. Tank valve selector switch | – Check in either L or R OPEN position as required |
| 2. EMERGENCY switch | – Activate |
| 3. L. CLSD (R. CLSD) indicator light | – Goes off |

CAUTION IF AN EMERGENCY LANDING IS REQUIRED, CLOSE LONG RANGE FUEL TANK VALVE PRIOR TO TOUCHDOWN.

- | | |
|-------------------------------|----------|
| 4. Tank valve selector switch | – CLOSED |
|-------------------------------|----------|

NOTE Use of the EMERGENCY switch will override the main tank float switch and open only the preselected tank valve. Close the tank valve prior to landing or when the aux tanks are empty.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- | | |
|---------------------------------|------------------------------------|
| Vent and drain lines | – Condition, connected, no leakage |
| Aux tank(s) | – Secured, no leakage |
| For single-tank installations: | |
| Tank protective panel | – Installed |
| Fuel transfer line(s) | – Condition, connected, no leakage |
| Tank valve mechanical indicator | – Check for closed indication |
| Electrical connectors | – Connected |
| Fuel quantity, each tank | – Remove filler cap, check |
| Filler cap(s) | – Secured |