

4.2 PRE-START CHECK

- | | |
|---|-------------------------------------|
| EMERGENCY (NORM/EMERG) switch | – Guarded (breakaway-wired to NORM) |
| Circuit breakers (control panel) | – In as required |
| Both FULL and L. CLSD, R. CLSD indicator lights | – On as required |

NOTE FULL indicator light comes on only when respective aux tank is filled to max capacity.

- | | |
|-------------------------------|-----------------------------|
| TRANSFER caution light | – Press to test |
| Tank valve selector switch | – Select either L or R OPEN |

4.3 SYSTEM OPERATION

CAUTION DURING FLIGHTS WITH ONLY ONE PILOT SEAT OCCUPIED, THE FUEL OF ONE LONG-RANGE TANK MUST BE TRANSFERRED IMMEDIATELY AFTER THE **TRANSFER** CAUTION LIGHT COMES ON IN ORDER TO AVOID EXCEEDING THE AFT-CG LIMIT.

- | | |
|-----------------------------------|-----------------------------|
| TRANSFER caution light | – Comes on |
| L. CLSD (R. CLSD) indicator light | – Applicable light goes off |
| Clock | – Note time |

NOTE Approx 40 min are required to transfer 200 l (one full aux tank).

- | | |
|-------------------------|-------------------|
| Main tank fuel quantity | – Note indication |
|-------------------------|-------------------|

After approx 5 minutes:

- | | |
|---|----------|
| Applicable FULL ind light and TRANSFER caution light | – Go off |
|---|----------|

When **TRANSFER** caution light comes on again repeat above steps for remaining aux tank or if aux tanks are empty:

- | | |
|--------------------------------|----------|
| Tank valve selector switch | – CLOSED |
| L. CLSD and R. CLSD ind lights | – On |
| Control panel circuit breakers | – Pull |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.