

8. HANDLING, SERVICING, AND MAINTENANCE

8.1 SERVICING

8.1.1 Refueling Auxiliary Tanks

Refuel helicopter supply and main tanks before refueling the aux tanks. When refueling aux tanks follow all precautions listed in the basic FLM, Section 8.

1. Establish electrical ground connection
2. Check that main fuel tank filler cap is closed.

CAUTION DRAIN VALVE MUST BE CLOSED BEFORE REFUELING AUX TANK.

3. Check tank valve mechanical indicator for closed indication.
4. Remove aux tank filler cap.
5. Electrically ground refueling nozzle to filler neck.
6. Service aux tank to required level.
7. Remove refueling nozzle. Disconnect ground cable.
8. Install filler cap, check that cap is locked.
9. Repeat above steps as required for remaining aux tank.
10. Remove electrical ground connection.

8.1.2 Defueling Auxiliary Tanks

The aux tanks can only be defueled via the main fuel tank. After defueling the required quantity from the main tank follow normal fuel transfer procedures.

8.2 MAINTENANCE

8.2.1 Auxiliary Tank Removal

1. Defuel aux tank as required.
2. Check tank valve mechanical indicator for closed indication.
3. Disconnect fuel, vent and drain lines and stow on tank hooks provided.
4. Install blanking caps and covers.
5. Disconnect electrical connector and secure to tank dummy connector.

6. Remove locking pins from rails.
7. Remove aux tank.
8. Install main tank floor cover.

■ 8.2.2 Auxiliary Tank Installation

NOTE Aux tanks are correctly installed with the filler neck facing aft and located on the outboard side.

1. Check aux tank and all lines for condition.
2. Remove main tank floor cover.
3. Perform drain valve functional check.
4. Position aux tank on rails. Make certain that stops on tank are engaged with forward locking pins.
5. Install locking pins, 2 each tank.
6. Remove blanking caps and covers.
7. Connect vent and drain lines.
8. Connect fuel transfer line and secure sleeve.
9. Connect electrical connector.
10. Install protective panel as required.