

2. LIMITATIONS

2.1 EXTINGUISHER BOTTLE PRESSURE LIMITS

The indicated pressure of each fire extinguisher bottle shall be within the limits (IND PRESS) defined for the applicable ambient temperature as shown on the required PRESSURE-TEMPERATURE CORRECTION TABLE placard.

NOTE Engines must be cold for pressure-temperature correction table values to be valid.

2.2 PLACARDS AND DECALS

Text:

DRUCK-TEMPERATUR VERGLEICHSTABELLE PRESSURE-TEMPERATURE CORRECTION TABLE					
°C TEMP	-51	-40	-28	-17	-7
°F TEMP	-60	-40	-20	0	+20
IND PRESS	110	127	148	174	207
	134	155	180	212	251
°C TEMP	+4	+16	+27	+38	+49
°F TEMP	+40	+60	+80	+100	+120
IND PRESS	249	304	367	442	532
	299	354	417	492	582

Location: Engine cowling (either LH or RH) adjacent extinguisher gauges viewing window.