

FIRE EXT. TEST ind light

- Press to test, both segments must come on

FIRE EXT. TEST switch

- Position I, indicator light LH (or aft) segment must come on
- Position II, indicator light RH (or forward) segment must come on
- Position 0, all segments must go off

★ To be checked each flight before takeoff.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.