

3. Bank angles above 45° and abrupt maneuvers – Avoid
4. LAND AS SOON AS PRACTICABLE

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Exterior Checks

- | | |
|--------------------------------|--|
| Battery switch | – On |
| Supply tank pumps | – On |
| Microfilters | – Drain fuel sample |
| Test button (each microfilter) | – Press, check respective FILT warning light comes on |

4.1.2 Prestart Checks

CAUTION DO NOT TAKEOFF WITH A FAULTY FUEL PUMP.

- | | |
|-------------------|---------------------------------------|
| ★ Fuel pumps (4) | – Check function |
| Main tank pumps | – On |
| Fuel pressures | – Check approx 0.5 kp/cm ² |
| Main tank pumps | – Off |
| Supply tank pumps | – On |
| Fuel pressures | – Check approx 1.0 kp/cm ² |
| Supply tank pumps | – Off |

★ To be checked each flight before takeoff.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.