

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

CAUTION LIGHT INDICATIONS

M PUMP SW 1 OFF

and/or

M PUMP SW 2 OFF

Conditions/Indications

Main tank fuel pump(s) switched off

- Respective **M PUMP SW OFF** caution light on during flight

Procedure

1. FUEL PUMPS, MAIN TANK switches – On
2. Supply tank fuel quantity – Monitor to make certain that fuel is transferring from main tank to supply tank

4. NORMAL PROCEDURES

Function of the **M PUMP SW OFF** caution lights can be tested during the "Fuel pumps (4) – Check function" test during the Pre-start Check.

The **M PUMP SW OFF** caution lights will come on during the start-up procedure until the main fuel pumps are switched on, which is the last step of starting the second engine (reason: making start-up procedure easier for the battery, if battery is the power supply).

The **M PUMP SW OFF** caution lights will also come on during flight if the main fuel pumps are switched off because the main tank is empty.

Monitor supply tank fuel quantity during flight to assure proper transfer of fuel from main tank.

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

No change in the basic Flight Manual data.