

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 WARNING LIGHT INDICATIONS

WARNING LIGHT INDICATIONS

GEN 1

or

GEN 2

Conditions/Indications

Generator failure

- Voltmeter indication normal (27 - 29 V)
- **GEN** warning light (affected generator) on

Generator overvoltage

- Voltmeter indication above normal (30 V or more)
- **GEN** warning light (normal generator) on

NOTE Normal generator is disconnected by reverse current of affected generator.

Procedure

• GENERATOR FAILURE

1. GENERATOR switch (affected generator) – OFF, then ON

If **GEN** warning light remains on:

2. GENERATOR switch (affected generator) – OFF
3. CURRENT IND switch – Select normal generator
4. Ammeter and voltmeter – Monitor

• GENERATOR OVERVOLTAGE

1. GENERATOR switch (affected generator) – OFF
2. **GEN** warning light (affected generator) – On
3. **GEN** warning light (normal generator) – Off
4. CURRENT IND switch – Select normal generator
5. Ammeter and voltmeter – Monitor

NOTE One generator alone will provide sufficient power for normal services. Non-essential DC-bus loads are shed automatically.

WARNING LIGHT INDICATIONS

GEN 1

and

GEN 2

Conditions/Indications

Both generators have failed or are disconnected from the power distribution circuit.

Procedure

1. Each GENERATOR switch in turn – OFF, then ON

If both **GEN** warning lights remain on:

2. Both GENERATOR switches – OFF
3. CURRENT IND switch – BUS BAR (BATT)
4. Electrical consumption – Reduce
5. Ammeter and voltmeter – Monitor
6. LAND AS SOON AS PRACTICABLE

Residual Battery Endurance					
Continuous load [A]	15	20	25	30	40
Time [min]	60	45	35	30	22
NOTE Calculations are based on an assumed minimum battery capacity of 15 Ah. Times include 10-min landing light operation and 10-min radio transmitting.					

WARNING LIGHT INDICATIONS**START 1**

or

START 2**Conditions/Indications**

During normal engine starting, activation of each starter motor circuit is indicated by the respective **START** warning light coming on. However, should a starter motor circuit failure occur:

- **START** warning light (affected engine) remains on after placing respective STARTER/IGN switch to Off.

Procedure

- | | |
|-----------------------------|--------|
| 1. Power lever(s) | – OFF |
| 2. Battery switch | – Off |
| 3. STARTERS circuit breaker | – Pull |

3.2 ENGINE EMERGENCY CONDITIONS

3.2.1 Inflight Restart

NOTE An inflight restart may be attempted after a flameout or shutdown subject to the pilot's evaluation of the cause of flameout.

Procedure

CAUTION DO NOT ATTEMPT INFLIGHT RESTART IF CAUSE OF ENGINE FAILURE IS OBVIOUSLY MECHANICAL.

- | | |
|----------------------------------|--|
| 1. Collective lever friction | – Adjust to maintain position of lever when released |
| 2. Electrical consumption | – Reduce |
| 3. Power lever | – OFF |
| 4. GENERATOR switch | – OFF |
| 5. EMERG FUEL VALVE switch | – OPEN |
| 6. FUEL PUMPS/SUPPLY TANK switch | – On |
| 7. STARTER/IGN switch | – Raise guard, place switch to ON; START warning light on |

CAUTION ENGINE GAS PRODUCER SECTION MAY LOCKUP AFTER AN INFLIGHT FLAMEOUT OR SHUTDOWN. THEREFORE, EXCEPT DURING AN EMERGENCY, INFLIGHT RESTART SHOULD NOT BE ATTEMPTED DURING THE TIME PERIOD BETWEEN ONE MINUTE AND TEN MINUTES AFTER FLAMEOUT OR SHUTDOWN.

At 15% N_1 :

- | | |
|-------------------------|-------------------------------------|
| 8. Power lever | – IDLE |
| 9. TOT and N_1 | – Monitor closely, observe TOT peak |
| 10. N_2 increase | – Monitor |
| 11. Engine oil pressure | – Positive indication |

At 58% N_1 :

- | | |
|---------------------------------|--|
| 12. STARTER/IGN switch | – Off, close guard; START warning light off |
| 13. GENERATOR switch | – ON |
| 14. Power lever | – FLIGHT |
| 15. Electrical consumers | – As required |
| 16. LAND AS SOON AS PRACTICABLE | |

If restart is not successful:

- | | |
|--------------------------------------|-----------|
| 17. Single engine emergency shutdown | – Perform |
|--------------------------------------|-----------|