

When N_2/N_{R0} are above 40%:

GENERATOR switch

– ON; monitor N_1

NOTE If N_1 decreases to below 59%:

GENERATOR switch

– OFF

Power lever

– Advance, N_1 max 70%

GENERATOR switch

– ON

4.1.2 Starting Second Engine

CURRENT IND switch

– Select operating generator

Ammeter (battery start)

– Check below 100 A

Second engine

– Start following procedure for first engine

After EPU starts:

Battery switch

– On

EPU

– Check disconnected

Fuel main pumps

– On

5. PERFORMANCE DATA

No change in the basic Flight Manual data.