

6. MASS AND BALANCE

No change in the basic Flight Manual data.

7. SYSTEM DESCRIPTION

The standard engine starting/ignition system controls are modified so that each engine's starter motor and ignition circuits are controlled by a common three-position STARTER/IGN switch and the generators by separate GENERATOR (ENG 1, ENG 2) switches. Activation of each starter motor circuit is indicated by a **START** warning light coming on.

NOTE When the optional continuous ignition system (FMS 11-3) is also installed, the STARTER/IGN switches have four positions, the fourth position being for activation of the ignition circuit alone.

The STARTER/IGN; ENG 1 and STARTER/IGN, ENG 2 switches on the center console switch panel are spring-loaded to the center off position when placed in the VENT position. In the detent-locked ON position each switch supplies electrical power from the Main Bus via a common STARTER/IGN circuit breaker to the respective starter relay and ignition exciter unit. The starter relay in turn activates the starter motor circuit by supplying power from the Starter Bus and energizes the respective **START 1 (START 2)** warning light. A failure of the starter motor circuit will be indicated by the respective **START** warning light remaining on after placing the respective STARTER/IGN switch to OFF.

Holding the STARTER/IGN switch in the VENT position will supply electrical power only to the respective starter relay to allow for motoring the engine without ignition. Energizing the starter motor circuit is again indicated by the respective **START 1 (START 2)** warning light coming on.