

2. LIMITATIONS

2.1 LANDING AND SEARCH LIGHT LIMITS

2.1.1 Servomotors

Max operation 15 min

Min cooling period 3 min

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

Landing and search light	– Condition, function, set to desired position
--------------------------	--

4.2 LANDING AND SEARCH LIGHT OPERATION

COP/PIL selector switch	– As required
LAND LIGHT switch	– ON; ON indicator light comes on
SEARCHLIGHT switch	– As necessary to position light beam
LAND LIGHT switch	– OFF; ON indicator light goes off
SEARCHLIGHT switch	– IN and hold; CLOSED A. LOCKED indicator light comes on
SEARCHLIGHT switch	– Release; CLOSED A. LOCKED indicator light goes off

5. PERFORMANCE DATA

No change in the basic Flight Manual data.