

4. NORMAL PROCEDURES

4.1 DC POWER SYSTEM CHECK

- | | |
|---|---|
| EMERG DC-BUS pushbutton | – Press; EMERG DC-BUS caution light legend on |
| Equipment not connected to emerg DC-bus | – Off |
| EMERG DC-BUS pushbutton | – Release; EMERG DC-BUS caution light legend off |
| Equipment not connected to emerg DC-bus | – On |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.