

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Emergency DC-bus System	105-98133	1.5	1200	1800
Emergency DC-bus System	D134-1089	0.8	1200	960
Emergency DC-bus System	DSK 0-90013	0.8	1000	800

7. SYSTEM DESCRIPTION

The emergency DC power distribution bus provides select essential equipment with battery power under extreme emergency conditions, i.e. dual generator or main bus failure. Operating the clear plastic cover guarded EMERG DC-BUS pushbutton accomplishes the following:

- Activates a relay to connect the battery directly to the Emergency Bus and isolate the Emergency Bus from the other electrical power sources
- Disconnects the battery from the other electrical system buses and activates a relay to interrupt both generator power circuits
- Disconnects the EPU power control circuit
- Causes the pushbutton integral **EMERG DC-BUS** caution light legend to come on.

The following listed essential equipment may be connected to the emergency bus and are then powered directly by the battery:

- Engine Fire Warning
- Hydraulic System Control and Monitoring
- Emergency Fuel Valves
- Fuel Quantity Indication
- Main Tank Forward Fuel Pump
- Low Fuel Warning
- Instrument Lights
- Landing Light
- Engine Fire Extinguishing System (optional)
- Emergency Flotation System (optional)
- Fuel Jettison System (optional)
- Stability Augmentation System (optional)

And various avionic equipment to include but not limited to:

- Communication Control System
- Directional Gyro
- RMI (without ADF and VOR 2 function)
- Pilot's Artificial Horizon
- VHF I
- NAV I
- ATC-Transponder (without Mode C function)

The following engine instruments are self-sustaining and therefore not affected by a total loss of electrical power:

- N_1 RPM indicators
- N_2 and N_{R0} RPM indicator
- TOT indicators
- Dual TORQUE indicator