

2.10 ENVIRONMENTAL OPERATING CONDITIONS

2.10.1 Altitude/Ambient Air Temperature Limitations (see Fig. 2-3)

Min ambient air temperature -30 °C

EFFECTIVITY *If extreme low temperature kit 105-80006 installed and operational*

Min ambient air temperature -45 °C

EFFECTIVITY *0001-0320 Before SB 60-31*

Max ambient air temperature +40 °C

EFFECTIVITY *0321-9999, and 0001-0320 After SB 60-31*

Max ambient air temperature +54 °C

When operating in high ambient temperatures (+45 to +54 °C) at sea level, the oil temperatures must be closely monitored in particular during hover. The oil temperatures may be reduced at all times by either landing or transition to cruise flight.

EFFECTIVITY *ALL*

2.10.2 Engine Anti-icing

Engine anti-icing must be on when the ambient temperature is below +4 °C and visible moisture is present, except for takeoff and landing.

2.10.3 Pitot Heating

Pitot heating must be on when the ambient temperature is below +4 °C and visible moisture is present.

2.10.4 Icing Conditions

Flight into known icing conditions is prohibited.

2.10.5 Snow Conditions

Operation in snow is prohibited except when the Continuous Ignition System (see FMS 11-3) is installed and switched on.

The engine inlet deflector shield must be installed when operation in snow is expected. ■

After operation in snow, a post flight visual check of the compressor inlet must be conducted in accordance with Section 11, FMS 11-3, paragraph 4.4.

NOTE Record engine operation in snow in the journey logbook.

2.10.6 Battery Temperature Limitations

When the engines are started using the onboard battery at an OAT of below -30 °C, the battery shall be preheated to at least -30 °C.

When the engines are started using an external power unit at an OAT of -40 °C or below, the battery shall be preheated to at least -40 °C.