

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Exterior Checks

- | | |
|--------------------------------|--|
| Battery switch | – On |
| Supply tank pumps | – On |
| Microfilters | – Drain fuel sample |
| Test button (each microfilter) | – Press, check respective FILT warning light comes on |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.