

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

System/Equipment Designation	Part No.	Mass (kg)	Arm (mm)	Massmoment (kgmm)
Fuel Microfilters	105-83561	3.5	4600	16100
Fuel Microfilters	105-83562	4.4	4300	18920
Fuel Microfilters	105-83563	3.5	4600	16100
Fuel Microfilters	105-83556	4.4	4300	18920
Fuel Microfilters	105-83588	3.7	4400	16280

7. SYSTEM DESCRIPTION

A microfilter is installed in each engine's fuel supply system between the emergency fuel valve and the engine-mounted fuel filter. The microfilter will entrap not only contaminants but also ice crystals that may form at fuel temperatures below +4 °C so that the requirement for a fuel anti-icing additive can be eliminated.

Each microfilter is fitted with a differential pressure switch that will activate the respective **FILT** warning light when a differential of 1.2 to 1.4 psi is sensed, indicating that clogging of the filter element has begun. When the pressure differential reaches 4.0 psi (filter clogged) a bypass valve opens allowing unfiltered fuel to flow downstream.

NOTE The **FILT 1/FILT 2** warning lights will also come on whenever their respective engine-mounted fuel filter becomes clogged.