

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS

3.1.1 Automatic Mode Failure

Conditions/Indications

- No automatic follow-up response to cyclic stick inputs.
- Trim actuator runaway.

Procedure

1. FOLLOW-UP TRIM switch – MAN
2. Cyclic 4-way TRIM switch – Use as required

NOTE The automatic follow-up mode is disabled except for the F/U-TRIM pushbutton. Use of the F/U-TRIM pushbutton will therefore cause the fault to return.

3.1.2 Manual Mode Failure

Conditions/Indications

- No response to cyclic stick 4-way TRIM switch inputs.
- Trim actuator runaway.

Procedure

CAUTION DURING ENGINE SHUTDOWN, HOLD CYCLIC STICK IN NEUTRAL POSITION UNTIL ROTOR COMES TO A COMPLETE STOP.

1. FOLLOW-UP TRIM switch – OFF
2. LAND AS SOON AS PRACTICABLE

NOTE Full cyclic stick travel remains available, however, greater control forces may be necessary to overcome the spring loads.