

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

NOTE This functional check replaces the basic FLM trim actuator limit switches function check.

FOLLOW-UP TRIM switch – MAN

NOTE During ground operations, FOLLOW-UP TRIM switch must be in either OFF or MAN positions.

TRIM (4-way) switch – Press forward and hold until cyclic stick reaches limit

Cyclic stick – Pull aft, check for full travel

NOTE Check actuator limit switch operation (motor audibly stops) and make certain that cyclic stick full travel is available in opposite direction to that trimmed.

TRIM (4-way) switch – Check each remaining cyclic control direction (aft, left, right) as above, then trim stick to center position

Cyclic stick – Place and hold in any position from center

F/U-TRIM pushbutton – Press until new neutral point is obtained, then release; cyclic stick remains in trimmed position

FOLLOW-UP TRIM switch – ON

Cyclic stick – Place in all four quadrants; check automatic function of actuator follow-up neutral point repositioning

★ FOLLOW-UP TRIM switch – MAN

★ TRIM (4-way) switch – Trim cyclic stick to center

★ To be checked each flight before takeoff.

4.2 PRE-LANDING CHECK

FOLLOW-UP TRIM switch – MAN

5. PERFORMANCE DATA

No change in the basic Flight Manual data.