

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 ENGINE EMERGENCY CONDITIONS

When under emergency OEI conditions and the operating engine's TOT nears the limit, switch the bleed air heating off.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Interior Check

- | | |
|-----------------------------------|---------------------------------|
| Vent control lever | – OFF or RAM AIR positions only |
| Bleed air heating MAN-AUTO switch | – Off |

4.2 SYSTEM OPERATION

4.2.1 Ventilation

NOTE Make certain that both engines are stabilized at ground IDLE before operating blower.

- | | |
|--------------------|--------------------|
| Vent control lever | – BLWR, if desired |
|--------------------|--------------------|

4.2.2 Automatic Controlled Heating

- | | |
|-----------------------------------|------------------------------------|
| Vent control lever | – As desired |
| Bleed air heating MAN-AUTO switch | – AUTO; HEATING indicator light on |
| TEMP CONTROL knob | – Set to desired temperature |

4.2.3 Manual Controlled Heating

NOTE Manual temperature control is for use as a backup should the normal automatic temperature control malfunction.

- | | |
|-----------------------------------|---|
| Vent control lever | – As desired |
| Bleed air heating MAN-AUTO switch | – MAN; HEATING indicator light on |
| DECR-INCR switch | – Manually regulate cabin temp as desired |