

4.2.4 System Shutdown

- | | |
|-----------------------------------|------------------------------------|
| Bleed air heating MAN-AUTO switch | – Off; HEATING indicator light off |
| Vent control lever | – Off |

5. PERFORMANCE DATA

5.1 EFFECTS OF BLEED AIR HEATING

For operations with bleed air heating ON (max heating power), the basic FLM performance data charts (Section 5) are affected as follows:

- When using gross mass as a parameter, add 3% to the actual gross mass value before entering the chart; e.g. when actual gross mass is 2350 kg, enter chart using 2421 kg as the corrected value.
- When gross mass is a chart result, subtract 3% from the derived chart value to obtain the corrected gross mass; e.g. when the derived gross mass is 2350 kg, the corrected gross mass is then 2280 kg.