

2. LIMITATIONS

2.1 SYSTEM LIMITS

The firing of aerial flares is permissible only when necessary for safety reasons and when local regulations governing use of pyrotechnics are complied with.

Min height for flare firing 1000 ft AGL

2.2 SYSTEM INSTALLATION LIMITS

The aerial flare system shall not be installed together with the following other optional equipment:

Emergency Flotation System	FMS 10-22
External Loudspeakers (only rear cross-tube mounted loudspeakers)	FMS 10-23

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS

3.1.1 Aerial Flare Misfire

Conditions/Indications

Flare cartridge fails to fire

Procedure

WARNING WHEN LANDING AFTER A MISFIRE, KEEP FLARES POINTED AWAY FROM PERSONNEL AND OCCUPIED AREAS.

- | | |
|----------------|--|
| 1. FIRE switch | – Select remaining flare cartridge as required |
| 2. PWR switch | – OFF |

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

PWR switch	– OFF
FIRE switch	– OFF
Mount assembly	– Condition, integrity
Knurled rings and lock rings	– Secured
Protective discs or flare cartridges	– Installed as required