

4.2 FIRING AERIAL FLARES

WARNING AERIAL FLARE SYSTEM IS FOR INFLIGHT USE ONLY.

- | | |
|-------------------------------|---|
| Altitude (best area coverage) | – 1200 ft AGL |
| PWR switch | – ON |
| FIRE switch | – 1 or 2, then release; single flare launched |
| FIRE switch | – Select remaining flare as required; re-
maining flare launched |
| PWR switch | – OFF |

5. PERFORMANCE DATA

No change in the basic Flight Manual data.