

2. LIMITATIONS

2.1 SLOPE OPERATIONS

When configured with the standard landing gear and the WSPS, slope operations, when facing into the slope, are limited to slopes of 9 degrees (*Model C Variants*) and 7 degrees (*Model S Variants*). The lower cutter may contact the ground during takeoffs and landings on slopes exceeding these limits.

When configured with the high clearance landing gear and the WSPS, slope operations limits as stated in FMS 10-42 shall apply.

2.2 SYSTEM INSTALLATION LIMITS

The WSPS is not physically compatible with the following other optional equipment:

Single Windshield Wiper	– FMS 10-3
Searchlight (SX 16)	– FMS 10-35, FMS 10-38, and FMS 10-60
Landing and Search Light	– FMS 10-34
Emergency Flotation System	– FMS 10-22

3. EMERGENCY AND MALFUNCTION PROCEDURES

In the event of a wire strike, LAND AS SOON AS POSSIBLE and perform engine shut-down. Do not attempt further flight until an inspection and repair is carried out by qualified personnel.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Exterior Check

WSPS components	– Condition, security of attachment, deformation or mechanical damage.
Lower cutter assembly	– Condition, evidence and indication of ground contact
Cutter blades	– Condition, evidence and indication of wire strike (paint chips on deflector; damaged, missing or broken protective coating on blades, notches, etc).

NOTE If a wire strike has occurred, inspect the WSPS fixed provisions (upper and lower) as well as surrounding cell structure for evidence of damage. Maintenance action is required (refer to appropriate BO 105 Maintenance Manual).

WARNING DURING TRANSITION TO FORWARD FLIGHT, AN EXCESSIVE NOSE-LOW ATTITUDE MAY RESULT IN THE WSPS LOWER CUTTER CONTACTING THE GROUND. WHEN TAKING OFF AND LANDING ON UNEVEN TERRAIN, EXTREME CARE SHOULD BE EXERCISED TO PREVENT CONTACT OF LOWER CUTTER WITH THE GROUND.