

8. HANDLING, SERVICING, AND MAINTENANCE

8.1 SERVICING WINDSHIELD WASHER RESERVOIR

The windshield washer reservoir is located on the cargo compartment floor aft of the RH sliding door. The 6-liter capacity reservoir should be replenished using a mixture of distilled water, approved cleaning fluid (SC3) and ethyl alcohol.

The mix ratio, dependent upon the average daily ambient temperature, is shown in the following table:

Average Daily Temperature	Parts Cleaning Fluid	Parts Distilled Water	Parts Ethyl Alcohol
Above +4 °C	1	9	—
+4 °C to -7 °C	1	4	5
-8 °C and below	1	—	9