

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

WARNING LIGHT INDICATIONS

T. PLUG

Conditions/Indications

Metal particles detected in transmission oil

Procedure

● IF ONLY XMSN CHIP WARNING IS INSTALLED:

1. XMSN oil temperature and XMSN oil pressure – Monitor

If temperature and pressure are normal:

2. LAND AS SOON AS PRACTICABLE

If temperature and/or pressure are abnormal:

3. LAND IMMEDIATELY

● IF BOTH XMSN AND GB CHIP WARNING ARE INSTALLED:

1. T PLUG selector sw (overhead panel) – Place to MAIN and TR/IGB positions while observing the **T. PLUG** warning light. The warning light will remain on in the position of the affected unit.

If the MAIN transmission is affected:

2. XMSN oil temperature and XMSN oil pressure – Monitor

If temperature and pressure are normal:

3. LAND AS SOON AS PRACTICABLE

If temperature and/or pressure are abnormal:

4. LAND IMMEDIATELY

If the tail-rotor/intermediate gearbox is affected:

2. LAND AS SOON AS PRACTICABLE