

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

Landing/search light unit – Condition, stowed

Before Night Flights:

Landing/search light – Check function, position as desired

LDG LIGHT indicator light – Check function

4.2 LANDING/SEARCH LIGHT OPERATION

- CAUTION**
- LANDING/SEARCH LIGHT LAMP GENERATES EXTREME HEAT; MINIMIZE ITS USE WHEN ON THE GROUND (DRY VEGETATION IGNITION HAZARD).
 - SWITCH LAMP OFF AND ALLOW TO COOL BEFORE LANDING IN DEEP SNOW.
 - STOW LIGHT UNIT USING THE LAMP CONTROL SWITCH RETR POSITION ONLY.

The following table explains the control switch functions:

SWITCH	POSITION	FUNCTION
Lamp Control	ON	Switches the lamp on.
	OFF	Switches the lamp off.
	RETR	Retracts and automatically rotates light unit to its stowed position.
Directional Control	FWD - AFT	Extends or respectively retracts light unit to any position between fully extended and fully retracted. Limit switches restrict extend and retract travel.
	L - R	Rotates light unit in respective direction a full 360° continuously, no rotational limit.