

6. MASS AND BALANCE

No change in the basic Flight Manual data.

7. SYSTEM DESCRIPTION

7.1 Instrument Lights

Power to two dimmable instrument light circuits (panels and annunciators) is controlled by a three-position INSTRUMENT LIGHTING switch located on the overhead console. With this switch in either the NIGHT or NVG position, 28V DC is supplied from the Main Bus via a fuse to a dim controller for each circuit.

The INSTR. rheostat controls the light intensity (1 to 100%) for illumination of the instruments, control panels, overhead console, standby compass, and OAT indicator. The ANNUNC. rheostat controls the intensity (10 to 60%) of the annunciator lights (except for overhead-console mounted annunciator lights that are not dimmable).

A whip light at the left of the center console switch panel is also powered when the INSTRUMENT LIGHTING switch is in either the NIGHT or NVG position. The whip light, however, has its own on-off switch and the light intensity is not affected by either rheostat control.

7.1.1 Annunciator Lights

When the LAMP TEST pushbutton on the overhead console is pressed, all annunciator lights (except the two **F** [Fire] and the **LIMIT** [MM ind] lights) will come on. Each annunciator light segment has two lamps so that failure of a single lamp will produce only a dimming effect. If a segment fails to light, it indicates either the failure of both lamps or a defective circuit.

NOTE If the INSTRUMENT LIGHTING switch is in the NIGHT position during the lamp test, some lamps will be dimmed while others will be on with full intensity. Therefore, the INSTRUMENT LIGHTING switch should be in the OFF position to check proper functioning of the lamps (all lamps at full intensity).

