

2. LIMITATIONS

2.1 KINDS OF OPERATION

Operation is approved only when under Visual Flight Rules (VFR) by day and night.

2.2 AIRSPEED LIMITS

When the FLIR system is installed, the V_{NE} is limited to 120 KIAS or the value stated in the V_{NE} table (basic FLM, Section 2) reduced by 15 KIAS, whichever value is less.

2.3 SYSTEM LIMITS

FLIR is not to be used as an aid to navigation or for terrain avoidance.

The monitor shroud shall be installed when flying at night.

2.4 SYSTEM INSTALLATION LIMITS

Additional limitations apply when the FLIR system is installed together with the following equipment:

Dual Controls (FMS 10-5)

The LH yaw pedals, cyclic and collective controls shall be removed when the monitor is installed in the cockpit position.

Emergency Flotation System (FMS 10-22)

The FLIR system shall not be installed simultaneously with Flotation System, FMS 10-22. Only the MHC-STC BO-105 Floats (P/N 105-85189) shall be used in combination with the FLIR system.

Special Takeoff and Landing Procedures (FMS 11-4)

Category A operations are prohibited when the FLIR System is installed.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

The FLIR system is to be operated in accordance with the BSS 400 Dual Safire Operator's Manual.

4.1 PREFLIGHT CHECK

4.1.1 Exterior Check

- | | |
|---|---|
| Bolster | – Security of attachment to cross tubes |
| Turret and PA/antenna actuator assembly | – Security of attachment to bolster |