

4.1.2 Interior Check

- | | |
|----------------------|--------------------|
| Monitor | – Secured |
| Equipment rack | – Secured |
| All cables | – Secured |
| Lap top control unit | – Correctly stowed |

4.2 CRUISE CHECK

- | | |
|--------------------|--|
| Antenna controller | – Press DOWN pushbutton; green light goes off, after approx 15 seconds amber light comes on. |
|--------------------|--|

4.3 PRE-LANDING CHECK

- | | |
|--------------------|--|
| Antenna controller | – Press UP pushbutton; amber light goes off, after approx 15 seconds green light comes on. |
|--------------------|--|

5. PERFORMANCE DATA**5.1 RATE OF CLIMB**

Installation of the FLIR system affects the AEO and OEI rate-of-climb performance. At the best climb speed (V_Y) the rate of climb is decreased by 10 fpm.