

2. LIMITATIONS

No change in the basic Flight Manual data.

3. EMERGENCY AND MALFUNCTION PROCEDURES

EFFECTIVITY *Single-inverter Systems with automatic switch-over*

CAUTION LIGHT INDICATIONS

AC
FAIL

Conditions/Indications

Failure of inverter/All AC consumers except those powered by 26V AC emergency bus lose power

Procedure

1. INV switch – OFF

EFFECTIVITY *Single-inverter Systems with manual switch-over*

CAUTION LIGHT INDICATIONS

AC
FAIL

Conditions/Indications

Failure of inverter/All AC consumers lose power

Procedure

1. AC POWER switch – EMER; consumers powered by 26V AC emergency bus regain power
2. INV switch – OFF