

EFFECTIVITY *Dual-inverter System with automatic switch-over*

CAUTION LIGHT INDICATIONS

INV 1

or

INV 2

Conditions/Indications

Failure of respective inverter

Procedure

1. INV circuit breaker (affected inverter) – Pull

EFFECTIVITY ALL

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Interior Check

★ Overhead panel:

AC POWER switch (if installed) – NORM, guarded

4.1.2 Starting Second Engine

INV switch (if installed) – ON

5. PERFORMANCE DATA

No change in the basic Flight Manual data.