

2.19 PLACARDS AND DECALS

The placards and decals depicted herein are typical and presented in either the English language or bilingual (German-English). Other languages may be used as a customer option. Slight formal differences from the installed placards and decals do not affect the information presented therein.

EFFECTIVITY For IAC-AR registered helicopters only

During flights in metric airspace, check the altitude using the conversion table placard (ft → m and hPa → in. Hg) located on the windshield center post in pilot's field-of-view.

EFFECTIVITY All

Text:

**THIS HELICOPTER MUST BE OPERATED
IN COMPLIANCE WITH THE OPERATING
LIMITATIONS SPECIFIED IN THE LBA
APPROVED ROTORCRAFT FLIGHT MANUAL**

**THE "AIRWORTHINESS
LIMITATIONS" SECTION OF THE
ROTORCRAFT MAINTENANCE
MANUAL MUST BE COMPLIED WITH.**

Location: In pilot's field-of-view

Text:

PRESSURE ALTITUDE-FT	OAT °C									
	-45	-30	-20	-10	0	+10	+20	+30	+40	+50
0	145	145	145	145	145	145	144	141	139	137
2000	145	145	145	145	144	141	139	136	134	132 129
4000	145	145	143	141	139	136	134 132	132 128	129 123	
6000	145	141	138	136	134 132	131 127	129 122	127 118		
8000	140	136	133 132	131 127	129 122	126 117	123 113	119 108		
10000	135 134	131 127	128 122	126 117	122 112	118 107	114 103			
12000	130 124	126 117	122 112	117 107	113 102	108 97	104 93			
14000	124 113	117 106	112 102	108 97	103 92	99 88		NOTE MAINTAIN IN SPEED RANGE FROM VNE MINUS 20Kts TO VNE 98-102% ROTOR RPM		
16000	114 103	107 96	103 91	98 87	93 82	89 78				
17000	109 98	102 91	98 86	93 81	88 77					
	VNE-KIAS GROSS WEIGHT (kg)									2100 2400

Location: In pilot's field-of-view

EFFECTIVITY Variants CB-4, CDN-B-4, CBS-4, and CDN-BS-4

Text:

For gross weights between 2400kg and 2500kg: $V_{NE} = V_{NE\ 2400kg} - 10\%$
Rotor RPM: 98% to 102% at any speed

Location: In pilot's field-of-view

EFFECTIVITY ALL

Text:

**DURING GROUND OPERATION ONLY
SMALL CYCLIC STICK DISPLACEMENTS FOR FUNCTIONAL TESTS**

Location: In pilot's field-of-view

Text:

**MAX. BODENLAST 600 kg/m²
LADEGUT VERZURREN
ZUL. BELASTUNG PRO VERZURRÖSE 100 kg
ZUL. BELASTUNG PRO GEWINDEEINSATZ 200 kg

MAX. WEIGHT PER sq. ft. 120 lbs
CARGO TO BE SECURED
MAX LOAD PER EYE 220 lbs
MAX LOAD PER INSERT 440 lbs**

Location: Cargo compartment

EFFECTIVITY *RAI certified helicopters only*

Text:

**MAX. CARGO IS LIMITED BY
WEIGHT AND BALANCE CONSIDERATION**

Location: Cargo compartment

EFFECTIVITY *ALL*

Text:

**MAX ZULADUNG 20kg
MAX LOAD 44lbs**

Location: Avionics equipment bay

Text:

**BEI FASS-ODER KANISTERBETANKUNG EINGEBAUTES
SIEB VERWENDEN
FOR BARREL OR GAS CAN REFUELING USE INSTALLED
SCREEN
BEI BETRIEB UNTER +4°C ENTEISUNGSZUSATZ NACH
MIL-I-27686
VOLUMENANTEIL: MAX. 0,15%; MIN. 0,035%
FOR OPERATION BELOW +4°C (40°F) ADD ANTI-ICING
ADDITIVE MIL-I-27686
CONCENTRATION BY VOLUME: MAX. 0,15%; MIN. 0,035%**

Location: Adjacent fuel tank filler neck

Text:

KRAFTSTOFF	570 LITER
FUEL CAP.	150 US GAL
MIL-T-5624:	JP-4, JP-5
MIL-T-83133:	JP-8
ASTM-D-1655:	JET A, A-1, B

Location: Adjacent fuel tank filler neck

Text:

4l	max	4l
Oil-System		
4,5l (1,2 US Gal)		
○	nicht mischen! do not mix!	○
3l		3l
○	<u>Nachfüllen</u> Add Oil	○
2l	MIL-L-23699 (MIL-L-7808F,G)	2l

Location: Engine oil tank

Text:

**ÖL 10,3 LITER
OIL 2.7 US GAL
MIL-L-23699**

Location: Adjacent main transmission filler neck

Text:

TÜR-NOTABWURF
TÜRE ÖFFNEN
DANN ABWURFHEBEL
BETÄTIGEN
DOOR JETTISON
OPEN DOOR
THEN PUSH DOWN
EMERGENCY LEVER

Location: Interior each cockpit door – above door handle

Text:

SCHIEBETÜR
ÖFFNEN  OPEN
DRÜCKEN  PUSH
SCHIEBEN  SLIDE
SLIDING DOOR

Location: Interior LH sliding door – above door handle

Text:

SCHIEBETÜR
ÖFFNEN  OPEN
DRÜCKEN  PUSH
SCHIEBEN  SLIDE
SLIDING DOOR

Location: Interior RH sliding door – above door handle

EFFECTIVITY *After ASB BO105-60-110 and appropriate placard installed*

Text:

MIN CONTINUOUS 98%
MIN TRANSIENT 95%
ASB BO105 60-110

Location: Next to the triple RPM indicator

EFFECTIVITY *ALL*

