

2. LIMITATIONS

2.1 OCCUPANTS

All occupants, including the flight crew, must keep their seat belts fastened during flights with opened and/or removed door(s).

2.2 CENTER OF GRAVITY LIMITS

With clam shell doors removed, any load may protrude only so far aft that it does not reach an imaginary line drawn between the aft end of the skids and the tip of the tail skid.

The payload CG shall be located within the cargo compartment and the total helicopter CG limits must not be exceeded.

2.3 AIRSPEED LIMITS

Any door removed with remaining doors closed:

Power On Max 110 KIAS

Power Off Max 80 KIAS

Either or both sliding door(s) opened and secured
(regardless of status of other doors) Max 80 KIAS

When opening/closing sliding doors Max 80 KIAS

NOTE Avoid steady autorotation under 50 KIAS with clam shell doors removed and with all cockpit and sliding doors closed.

2.4 OPENING COCKPIT DOORS

Opening cockpit doors during flight is only permitted when performing hovering maneuvers.

3. EMERGENCY AND MALFUNCTION PROCEDURES

No change in the basic Flight Manual data.

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Interior Check

Loose objects and equipment — Either secured or removed

NOTE When the passenger bench seat is removed, the cabin rear-wall insulation blanket must also be removed.

Sliding doors — Secured open (as required)