

EFFECTIVITY *All with RNAV*

Text:

**AREA NAV. NOT TO
BE USED UNDER
IFR-CONDITIONS**

Location: Center console on RNAV Control/Display unit.

EFFECTIVITY *For Non-commercial IFR Flights*

Text:

IFR NICHT-GEWERBLICHER VERKEHR	
BIS 2,3 t	VON 2,3 t BIS 2,4 t
$V_{MAX} = V_{NE} - 10\%$	$V_{MAX} = V_{NE} - 15 \text{ Kt}$
$V_{MIN} = 45 \text{ Kt}$	$V_{MIN} = 45 \text{ Kt}$

Location: Adjacent V_{NE} -table placard, in pilot's field-of-view.

EFFECTIVITY *ALL*

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS

3.1.1 Static Pressure System Blockage

Conditions/Indications

Static pressure ports blocked

- Static pressure instruments (airspeed, altimeter, vertical speed) show unrealistic indications
- Pointer deflections may be slowed