

Procedure

1. EMERGENCY STATIC switch – ALTERNATE SOURCE

NOTE With ALTERNATE SOURCE selected the altimeter indication error increases. To obtain true altitude, subtract the value given for the indicated airspeed and flight condition as shown in the following table:

ALTIMETER CORRECTION TABLE EMERGENCY STATIC SOURCE			
KIAS	CLIMB (1500 fpm)	DESCENT (1500 fpm)	CRUISE Level Flight
50	70	6	23
60	74	14	32
80	98	40	57
100	—	77	93
120	—	—	137

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

The preflight check of the communication and navigation equipment required for IFR flight is to be carried out according to the Avionic Manual.

Check proper function of the optional equipment installed, in particular the SAS (FMS 10-29) or the AFCS (FMS 10-41).

5. PERFORMANCE DATA

No change in the basic Flight Manual data.

6. MASS AND BALANCE

6.1 EQUIPMENT LIST ENTRIES

The components of the LBA IFR Configuration may vary with each installation. Therefore, refer to the EQUIPMENT LIST, Section 6 in the basic FLM to obtain the necessary mass and center-of-gravity data of the components installed.

