

SECTION 3

EMERGENCY AND MALFUNCTION PROCEDURES

TABLE OF CONTENTS

	<u>Page</u>
3.1 GENERAL	3 - 1
3.1.1 Basic Rules	3 - 1
3.1.2 Memory Items	3 - 1
3.1.3 Operating Condition	3 - 2
3.1.4 Urgency of Landing	3 - 2
3.2 WARNING AND CAUTION LIGHTS	3 - 2
3.2.1 Warning Light Indications	3 - 3
BAT 60	3 - 3
BAT 70	3 - 4
F/F	3 - 5
FILT 1/FILT 2	3 - 6
GEN 1 or GEN 2	3 - 7
GEN 1 and GEN 2	3 - 8
HY. BLOCK	3 - 9
HYD 1	3 - 10
HYD 2	3 - 11
LIMIT	3 - 12
LOW FUEL	3 - 13
MAG PLUG 1/MAG PLUG 2	3 - 14
OIL COOL	3 - 15
R P M	3 - 16
T OIL or XMSN OIL	3 - 17
3.2.2 Caution Light Indications	3 - 19
EPU ON	3 - 19
L/R or ANTI ICING 1/ANTI ICING 2	3 - 20

	<u>Page</u>
3.3 ENGINE EMERGENCY CONDITIONS	3 - 21
3.3.1 Single Engine Failure - Hover IGE	3 - 21
3.3.2 Single Engine Failure - Hover OGE	3 - 22
3.3.3 Single Engine Failure - Takeoff	3 - 23
3.3.4 Single Engine Failure - Flight	3 - 24
3.3.5 Single Engine Landing	3 - 25
3.3.6 Single Engine Emergency Shutdown	3 - 26
3.3.7 Inflight Restart	3 - 27
3.3.8 Engine Overspeed - Driveshaft Failure	3 - 28
3.3.9 Engine Overspeed - Governor Failure	3 - 29
3.3.10 Engine Underspeed - Governor Failure	3 - 30
3.3.11 Compressor Stall	3 - 31
3.3.12 Droop Compensation Failure	3 - 32
3.3.13 Engine Oil Pressure Low	3 - 33
3.3.14 Engine Oil Temperature High	3 - 34
3.3.15 Double Engine Failure - Hover IGE	3 - 35
3.3.16 Double Engine Failure - Flight	3 - 36
3.3.17 Double Engine Emergency Shutdown	3 - 37
3.3.18 Autorotation	3 - 38
3.4 FIRE EMERGENCY CONDITIONS	3 - 39
3.4.1 Cabin/Cargo Compartment Fire	3 - 39
3.4.2 Electrical Fire	3 - 40
3.5 TAIL ROTOR FAILURE CONDITIONS	3 - 41
3.5.1 Tail Rotor Drive Failure - Hover	3 - 41
3.5.2 Tail Rotor Drive Failure - Flight	3 - 42
3.5.3 Fixed-pitch Tail Rotor Control Failures	3 - 43
3.5.4 Pedal Vibrations	3 - 44
3.6 SYSTEM EMERGENCY/MALFUNCTION CONDITIONS	3 - 45
3.6.1 Electrical Short Circuit	3 - 45
3.6.2 Cyclic Trim Actuator Failure/Runaway	3 - 46
3.6.3 Supply Tank Fuel Pump Failure	3 - 47
3.6.4 Servo Jam - Hydraulic System 2	3 - 48
3.6.5 Oil Cooler Fan Failure	3 - 49