

2. LIMITATIONS

Operation in snow is permitted only when the continuous ignition system is installed and operational.

The engine inlet deflector shield must be installed when operation in snow is expected.

For operation in snow or whenever conditions allow snow collection on the cabin roof or in the area of the engine inlets, the continuous ignition must be switched on and must then remain on until engine shutdown even if the criteria for usage has changed and is no longer existent.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 ENGINE EMERGENCY CONDITIONS

3.1.1 Single Engine Emergency Shutdown

Procedure

In addition to the basic FLM Single Engine Emergency Shutdown procedure, perform the following:

EFFECTIVITY P/N 105-96228 and 105-96229

1. CONT. IGNITION switch (affected engine) – Off

EFFECTIVITY P/N 105-96239

2. STARTER/IGNITION switch (affected engine) – OFF

EFFECTIVITY ALL

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

4.1.1 Exterior Check

WARNING FAILURE TO REMOVE ICE/SNOW ACCUMULATIONS WHILE ON THE GROUND CAN RESULT IN SERIOUS AERODYNAMIC AND STRUCTURAL EFFECTS WHEN IN FLIGHT.

In addition to performing the normal preflight check, particularly check the following:

Cabin roof, main-rotor head, main-rotor blades, tail rotor, and flight controls – Free of ice/snow

Fuel tank vents, static ports, and pitot tube – Free of ice/snow