

## FIRE EMERGENCY CONDITIONS

### 3.4 FIRE EMERGENCY CONDITIONS

#### 3.4.1 Cabin/Cargo Compartment Fire

##### Conditions/Indications

- Smoke, burning odor, flames

##### Procedure

##### ● ON GROUND

|                                      |                          |
|--------------------------------------|--------------------------|
| 1. Passengers                        | – Alert/Evacuate         |
| 2. Double engine emergency shut-down | – Perform                |
| 3. Fire                              | – Extinguish if possible |

##### ● IN FLIGHT

|                             |                                                    |
|-----------------------------|----------------------------------------------------|
| 1. Passengers               | – Alert                                            |
| 2. Fire                     | – Extinguish if possible                           |
| 3. Toxic fumes, smoke       | – Eliminate; Open sliding doors, windows and vents |
| 4. LAND AS SOON AS POSSIBLE |                                                    |

After landing:

|                                      |           |
|--------------------------------------|-----------|
| 5. Double engine emergency shut-down | – Perform |
|--------------------------------------|-----------|

## FIRE EMERGENCY CONDITIONS

### 3.4.2 Electrical Fire

#### Conditions/Indications

- Odor of burning insulation and/or acrid smoke

#### Procedure

##### ● ON GROUND

|                                      |                          |
|--------------------------------------|--------------------------|
| 1. Passengers                        | – Alert/Evacuate         |
| 2. Double engine emergency shut-down | – Perform                |
| 3. EPU, if connected                 | – Disconnect             |
| 4. Fire                              | – Extinguish if possible |

##### ● IN FLIGHT

|                                |                          |
|--------------------------------|--------------------------|
| 1. Passengers                  | – Alert                  |
| 2. Both STARTER/GENERATOR sw   | – Off                    |
| 3. Battery sw                  | – Off                    |
| 4. Fire                        | – Extinguish if possible |
| 5. Electrical consumption      | – Reduce                 |
| 6. Battery sw                  | – On                     |
| 7. CURRENT IND sw              | – BUS BAR (BATT)         |
| 8. Ammeter and voltmeter       | – Monitor                |
| 9. LAND AS SOON AS PRACTICABLE |                          |

| Residual Battery Endurance                                                                                                                                      |    |    |    |    |    |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|----|----|----|----|----|
| Continuous load [A]                                                                                                                                             | 15 | 20 | 25 | 30 | 40 |
| Time [min]                                                                                                                                                      | 60 | 45 | 35 | 30 | 22 |
| <b>NOTE</b> Calculations are based on an assumed minimum battery capacity of 15 Ah. Times include 10-min landing light operation and 10-min radio transmitting. |    |    |    |    |    |

If indications of electrical fire continue:

|                              |                                   |
|------------------------------|-----------------------------------|
| 10. Battery sw               | – Off if flight conditions permit |
| 11. LAND AS SOON AS POSSIBLE |                                   |