

Engine oil pressure indicators – Check positive indication

At 58% N_1 :

Starter switch – Off

Ignition switch – Off

When N_2/N_{R0} are above 40%:

Generator switch – On; monitor N_1

If N_1 decreases to below 59%:

Generator – Off

Power lever – Advance, N_1 max 70%

Generator – On

4.4.2 Starting Second Engine

CURRENT IND switch – Select operating generator

Ammeter (battery start) – Check below 100 A

Second engine – Start following procedure for first engine

After EPU starts:

Battery switch – On

EPU – Check disconnected

4.5 SYSTEM CHECKS

4.5.1 ★ Hydraulic Checks

WARNING • BOTH HYDR SYSTEMS SHALL BE OPERATIONAL. TAKEOFF WITH A KNOWN OR SUSPECTED HYDR SYSTEM FAILURE IS PROHIBITED.

• TAKEOFF WITH SYSTEM 2 SELECTED AS THE OPERATING SYSTEM IS PROHIBITED (THERE IS NO AUTOMATIC CROSS-OVER FROM SYSTEM 2 TO SYSTEM 1).

• DO NOT OPERATE THE HYDRAULIC TEST SWITCH DURING FLIGHT.

NOTE • Hydraulic system checks may be performed between starting first and second engine at pilot's discretion.

• System 2 is always the operating hydraulic system after starting engines because the collective lever lock is engaged (collective-down micro switch activated).

EFFECTIVITY *Hydraulic Systems **without** Positive Cross-over Indication*

- | | |
|--------------------------------|------------|
| HYD 1 and HYD 2 warning lights | – Off |
| HY BLOCK warning light | – Check on |

EFFECTIVITY *Hydraulic Systems **with** Positive Cross-over Indication*

- | | |
|-----------------------------------|------------|
| HYD 2 warning light | – Off |
| HYD 1 and HY BLOCK warning lights | – Check on |

EFFECTIVITY ALL

System 2 Check

- | | |
|-----------------------|---|
| | – |
| Cyclic stick | – Check ease of movement (not more than 3 cm from neutral) all four directions, return to neutral |
| Collective lever lock | – Release |
| Collective lever | – Check ease of movement, return to full down |

Cross-over Check

- | | |
|-----------------------|--------------------------------|
| Hydraulic test switch | – Place in RESET, then release |
|-----------------------|--------------------------------|

EFFECTIVITY *Hydraulic Systems **without** Positive Cross-over Indication*

- | | |
|------------------------|-------------------------------------|
| HY BLOCK warning light | – Off |
| HYD 1 warning light | – Monitor closely; light must flash |

- NOTE**
- If flashing of the **HYD 1** warning light is not noticed, place the hydraulic test switch in HYDR 2 position and repeat the system check making a short-duration cyclic stick displacement either prior to or during the cross-over.
 - If the **HYD 1** warning light does not flash then repeat the cross-over check while a qualified person visually monitors the hydraulic system to verify that control has returned to System 1.
 - Helicopters having optional hydraulic-powered equipment or systems, the **HYD 2** warning light may also come on for approx 2 seconds.

EFFECTIVITY *Hydraulic Systems **with** Positive Cross-over Indication*

- | | |
|-----------------------------------|-------|
| HYD 1 and HY BLOCK warning lights | – Off |
|-----------------------------------|-------|

- NOTE** Helicopters having optional hydraulic-powered equipment or systems, the **HYD 2** warning light may also come on for approx 2 seconds.

EFFECTIVITY ALL

Hydraulic test switch guard

– Close

System 1 Check

Cyclic stick

– Check ease of movement all four directions, return to neutral

Collective lever

– Check ease of movement, return to full down and lock

HYD 1, HYD 2 and HY BLOCK warning lights

– Check off

4.5.2 Electrical and Avionic Checks

Electrical system

– Functional check

Each generator in turn

– Off

Voltmeter

– Check not less than 27 V each generator

Respective **GEN** warning light

– On

Both generators

– On, warning lights off

CURRENT IND switch

– Select each GEN position and check that the loads are approx equal, leave switch in BUS BAR (BAT) position

★ COMM/NAV equipment

– On and check

★ All other instruments and equipment

– Check and set

