

4.5.2 Miscellaneous Checks

ANTI-ICING system	– Check as required
ENG. 1/ENG. 2 switches	– On
ANTI ICING 1/ANTI ICING 2 or L/R caution lights	– On
TOT	– Note increase
ENG. 1/ENG. 2 switches	– Off
ANTI ICING 1/ANTI ICING 2 or L/R caution lights	– Off
TOT	– Note decrease

4.6 ★ PRE-TAKEOFF CHECK

4.6.1 ★ On Ground

Crew and passengers	– Briefed
Passenger safety belts	– Fastened
Doors	– Closed, locked
Warning/caution lights	– Off
NOTE OIL COOL warning light (if installed) may remain on until after placing power levers full forward.	
Cyclic stick	– Check centering device secured
CAUTION IF ENGINES HAVE BEEN SHUT DOWN FOR MORE THAN 15 MINUTES, STABILIZE AT IDLE SPEED FOR 1 MINUTE.	
Power levers	– Smoothly to FLIGHT
OIL COOL warning light (if installed)	– Check off
N_R/N_2	– Check RPM warning and low rotor RPM audio tone on between 75% and 95%
	– Trim to 98%
NOTE Adjust the volume of the beeping tone as required.	
Torque	– Synchronize
Engine and XMSN instruments	– Check in green range
Fuel quantity indicator	– Check readings
Voltmeter	– Check 27–29V
Ammeter	– Check ΔI (LH–RH) < 10 A
Bleed air consumers	– As required
Optional equipment controls	– As required
Collective lever lock	– Check released
Collective lever friction	– Adjust as required