

SECTION 7

SYSTEM DESCRIPTION

7.1 GENERAL

This section contains general information that applies specifically to standard equipped helicopters serial number S-161 and subsequent. Refer to the BO 105 Maintenance Manual for information pertaining to earlier serial numbered helicopters.

7.2 LOCATION AREAS (see Fig. 7-1)

7.2.1 Nose Compartment

The nose compartment located forward of the cabin area provides a location for the battery (Model C Variants) and other electrical system components. Access is provided by a nose door fitted with an external power unit (EPU) connector access flap.

7.2.2 Cabin

The cabin area comprises the cockpit and passenger compartment.

A hinged jettisonable door on either side permits direct access to the cockpit. Large bubble-type acrylic windshields and clear acrylic windows in the crew doors and roof allow for good visibility.

A sliding door is located on either side of the fuselage for direct access to the passenger compartment. A large acrylic window is installed in each door.

7.2.3 Cargo Compartment

The cargo compartment may be separated from the cabin by a removable insulating divider. The engine deck forms the roof of the cargo compartment and acts as a firewall. Access to the compartment is from the aft end provided by two clamshell doors.

7.2.4 Avionics Equipment Bay

An avionics equipment bay is located beneath and at the aft end of the cargo compartment. This bay provides for installation of avionics equipment and is usually equipped with a forced-air ventilation system. Access is provided through a hinged and latched panel in the cargo compartment floor.

7.2.5 Tail Boom

The root of the tail boom is attached to the fuselage at an integral extension of the engine deck. The tail boom consists of a conical structure with a vertical fin. The tail rotor system